4ALL combinable dispenser kit

B&M SKU ID560.K3 | Idral code 560.K3

Routine care

Clean finished surfaces with water and soap. Avoid aggressive or abrasive cleaners and use a soft cloth.

The reliability of the valve depends on water quality. Refer to the manufacturer troubleshooting table and genuine spare-parts sheet when service is required.

Keep the sensor window clean and free of obstructions. Use a non-abrasive cloth so the window is not scratched.

Inspect and clean the water inlet filter regularly. Isolate the water supply before removing the solenoid valve or filter.

Check the soap level weekly. Use liquid soap with a viscosity of 1000–3500 cps.

For a seasonal shutdown, empty and clean the tank, fill it with water and activate the dispenser repeatedly for 2–3 minutes to flush the circuit.

Keep dryer air inlets and outlets unobstructed and check for dust accumulation.

Service

Use the original manufacturer instructions for component servicing and troubleshooting.

Source: Idral ISTA26-00. This summary accompanies the original manufacturer instructions supplied separately. Read the original instructions for complete safety information, model diagrams and service procedures.