INSTALLATION GUIDANCE

Concealed Anti-Blocking Shower Tap

B&M SKU: ID08540/E-30F Idral code: 08540/E-30F

Installation sequence

1 Check the product, exact variant and all supplied components against the accompanying Idral technical drawing before installation.

2 Isolate the water supply and flush the pipework thoroughly to remove debris before making final connections.

3 Mount the valve or mixer at the dimensions and finished-wall depth shown in the technical drawing, keeping the cartridge and filters accessible for service.

4 Connect the supplies to the marked inlets and fit check valves, filters and flow limiter where supplied.

5 Fit the anti-blocking control without preload. Restore supplies and confirm that water is delivered only after the control is released, then verify the specified cycle and shut-off.

Important

Installation should be completed by competent personnel. The supplied Idral technical drawing, product-specific safety requirements and local water/electrical regulations remain authoritative.