

INSTALLATION GUIDANCE

White thermoformed seat cover For EASY WC with front opening

B&M SKU: ID11200/E Idral code: 11200/E

Installation sequence

- 1 Confirm the official WC compatibility and seat-fixing dimensions before installation.
- 2 Fit the hinge and fixing components to the WC pan as shown in the manufacturer's instructions.
- 3 Align the seat correctly on the pan, then secure the fixings without damaging the ceramic.
- 4 Check that the seat is stable and that any lid or moving parts operate freely.

Important

The accompanying technical specification is the reference for dimensions, materials, mounting details and supplied components. Installation should be completed by a competent installer.

INSTALLATION GUIDANCE

White thermoformed seat cover For EASY WC with front opening

B&M SKU: ID11200/E Idral code: 11200/E

Idral assembly details

