INSTALLATION GUIDANCE

Anti-Vandal Shower Mixer with Diverter

B&M SKU: ID700.A2/1F-30 Idral code: 700.A2/1F-30

Installation sequence

1 Check the product, exact variant and all supplied components against the accompanying Idral technical drawing before installation.

2 Isolate the water supply and flush the pipework thoroughly to remove debris before making final connections.

3 Mount the valve or mixer on a rigid, aligned supply or in the prepared recess at the finished-wall depth and connection orientation shown in the technical drawing.

4 Connect hot and cold supplies to their marked inlets for mixer models. Fit supplied filters, check valves and flow regulators in the correct direction.

5 Fit the trim, outlet and control without obstructing the timed mechanism. Restore supplies slowly, check for leaks and verify the specified cycle and complete shut-off.

Important

Installation should be completed by competent personnel. The supplied Idral technical drawing, product-specific safety requirements and local water/electrical regulations remain authoritative.