

ArteCera

INSTALLATION INSTRUCTIONS

ArteCera S36 Ribbed Rectangular Bath 90 x 180
Product code: AC103611W

Important safety information

Installation must be completed by competent tradespeople in accordance with local building and plumbing requirements. Verify the supporting structure, service positions and compatibility of all selected components. Use two or more people to move the bath.

Before you begin

Inspect the bath against the current technical specification and confirm all selected components are suitable. The siphon is supplied with the bathtub. Compatible legs and panels, where applicable, and the waste, overflow, trap, taps or bath filler, sealant and plumbing connections are sold separately.

Installation sequence

- 1 Protect the bath and surrounding finishes. Do not drag the bath or place tools inside it.
- 2 Confirm the supporting floor is level, water-resistant and capable of carrying the filled bath and user load. Locate concealed services before drilling or cutting.
- 3 Dry-position the bath and mark its final outline, waste location and plumbing route. Maintain required clearances and future service access.
- 4 Set the bath level and fully supported in its final freestanding position.
- 5 Connect the supplied siphon and any compatible waste, overflow or trap in accordance with the component instructions. Do not overtighten fittings against acrylic.
- 6 Part-fill the bath and test every connection for leaks while access remains available. Correct any leak before closing access.
- 7 Apply neutral-cure sanitary silicone only at required junctions. Allow it to cure fully, then refill, drain and inspect all connections before use.

The product-specific technical and additional specification drawings take precedence over this general installation guidance.