

INSTALLATION GUIDANCE

EASY round stool

B&M SKU: ID15504.1 Idral code: 15504.1

Installation sequence

- 1 Assemble the components in the sequence shown in the accompanying Idral drawings.
- 2 Before each use, ensure that all height adjusters are set uniformly.
- 3 All four feet must rest firmly on the supporting surface.
- 4 Maximum load-bearing capacity: 150 kg.

Important


The accompanying technical specification is the reference for dimensions, materials, mounting details and supplied components. Installation should be completed by a competent installer.


INSTALLATION GUIDANCE

EASY round stool

B&M SKU: ID15504.1 Idral code: 15504.1

Idral assembly details




1	2	3	4	5	6
					
1x	1x	4x	1x	4x	6x

INSTALLATION GUIDANCE

EASY round stool

B&M SKU: ID15504.1 Idral code: 15504.1

Idral assembly details




Source: Idral ISTA23-01 / page 7

INSTALLATION GUIDANCE

EASY round stool

B&M SKU: ID15504.1 Idral code: 15504.1

Idral assembly details



Source: Idral ISTA23-01 / page 8