

CRISTINA

Installation Instructions

CRIFT48451 | Fractal Series | Chrome

Before installation

Installation must be carried out by a competent plumber. Check the full SKU, finish and supplied components. Verify the original drawing against the supplied product before drilling or making cutouts. Isolate supplies and protect finished surfaces.

Model and assembly

Wall-mounted spout, 1/2" connection, spout length 195 mm

Connections and fitting

Flush the pipework thoroughly before connecting the product. Follow the connection sizes, mounting ranges, pressure and temperature limits in the manufacturer drawing and supplied connection guidance. Use the supplied fixing parts and keep service connections accessible.

Commissioning and handover

Open the supplies gradually, inspect all connections for leaks and check operation of each fitted outlet, control and diverter. Resolve any leak before handover. Give the owner the manufacturer instructions and care guide.

Fitting reference

Cristina and B&M do not link a dedicated fitting leaflet for CRIFT484. Use the original dimensional drawing supplied with this SKU. Confirm the G1/2 connection and final spout position against the supplied part, protect the finish during assembly and follow the connection sealant manufacturer's guidance. Request model-specific fitting details from B&M or Cristina where needed.