Installation Guidance

MINIMAL timed basin/sink mixer – 200 mm

B&M SKU ID08135 | Idral code 08135

Installation sequence

1. Have a qualified installer prepare the supply connections using the original model drawing. Purge the pipes before connection and provide suitable water filtration.

2. Mount the tap on a smooth, flat wall and connect the supply using the model connection diagram. For the two-inlet mixer, fit the eccentric connections and sealing gaskets as shown in the original manual.

3. Open the supply and check all connections for leaks. Test the push button and automatic closure.

4. Confirm the nominal 15-second cycle at 3 bar. Use the product Technical Specification for the permitted timing adjustment and tolerance.

Important

Installation pressure: 1–5 bar (recommended 2–4 bar); water temperature 5–65 °C. Protect the valve from freezing.

The shared installation manual has a narrower pressure range than the product Technical Specification; this guidance uses the manual limit.

Source: Idral ISTA08-01. This summary accompanies the original manufacturer instructions supplied separately. Read the original instructions for complete safety information, model diagrams and service procedures.