Installation Guidance

MODERN timed basin tap with pre-mixer – anti-blocking

B&M SKU ID08510F/PM | Idral code 08510F/PM

Installation sequence

1. Have a qualified installer prepare the supply connections using the original model drawing. Purge the pipes before connection and provide suitable water filtration.

2. Align the tap with the basin-deck opening, fit its gasket and secure the supplied fixing kit. Connect the inlet hose or hoses using the model diagram and keep service connections accessible.

3. Connect the included 09026/1 mechanical pre-mixer to the hot and cold supplies and the tap inlet using the variant drawing. Set the mixed-water temperature before use.

4. Open the supply and check all connections for leaks. Test the push button after release and check that holding it does not cause continuous flow.

5. Confirm the nominal 15-second cycle at 3 bar. Use the product Technical Specification for the permitted timing adjustment and tolerance.

Important

Installation pressure: 1–5 bar (recommended 2–4 bar); water temperature 5–65 °C. Protect the valve from freezing.

Source: Idral ISTA02-01. This summary accompanies the original manufacturer instructions supplied separately. Read the original instructions for complete safety information, model diagrams and service procedures.