Installation Guidance

Timed WC support frame

B&M SKU IDTMON8-00000 | Idral code TMON8-00000

Installation sequence

1. Use clean, filtered water. Purge the supply pipes before connection and after a temporary shutdown.

2. Provide access to the supply isolation valve and service components. Protect the system from temperatures below 5 °C; drain it before freezing conditions.

3. Prepare the frame housing using ISTA46-00 Figure 01. Adjust the legs for the sanitary fitting height and secure the frame through the lower and upper fixing points.

4. Connect the supplied inlet pipe and drain pipe. Adjust inlet height, drain height and support-bar centres before closing the wall. Retain the service opening.

5. Open the supply, test the push button or lever and check the valve and connections for leaks. Nominal operation is approximately 6 seconds and 6 L per cycle at 3 bar.

Important

The supply must deliver at least 60 L/min at 1.2 bar dynamic pressure.

Operating pressure is 1–4 bar for this timed model. Follow the installation manual limit of 5–65 °C for the water supply.

Source: Idral ISTA46-00. This summary accompanies the original manufacturer instructions supplied separately. Read the original instructions for complete safety information, model diagrams and service procedures.