CRISTINA

Care and Maintenance

CRIIT47072 | Italy Series | Polished Black Chrome | No separate knob option

Routine cleaning

Clean finished surfaces regularly with a neutral soap-based detergent and a soft cloth, such as microfibre. Rinse thoroughly to remove cleaning residue and dry gently.

Protect the surfaces

Do not use acidic or caustic cleaners, their derivatives, abrasive powders, scouring pads, or metal or non-metal abrasive sponges. Avoid abrasive polishes. Keep construction chemicals and aggressive cleaning residues away from the fitting.

Marble knobs

For marble handles use a cleaner specifically suitable for marble, as Cristina instructs. Use a soft cloth and follow the cleaner instructions. Do not use acidic descalers, vinegar, abrasive tools or aggressive household cleaners on stone. Natural veining and colour variation are inherent to marble.

Outlets and servicing

If flow becomes reduced or uneven, ask a competent plumber to inspect the appropriate outlet, aerator or filter by the manufacturer method. Isolate the water before servicing. Use the correct service key and protect finished surfaces from tools.

Replacement parts

Quote CRIIT47072, purchase details and photographs when requesting assistance. Match the exact model and production revision. Request model-specific replacement references from B&M or Cristina before ordering.

Selected finish

Polished Black Chrome; No separate knob option. Screen and printed colours may differ from the actual surface.

Reference: Cristina manufacturer cleaning and maintenance guidance.