CRISTINA

Installation Instructions

CRIIT75372 | Italy Series | Polished Black Chrome | Matching metal knob

Before installation

Installation must be carried out by a competent plumber. Check the full SKU, finish and supplied components. Verify the original drawing against the supplied product before drilling or making cutouts. Isolate supplies and protect finished surfaces.

Model and assembly

External wall-mounted shower/bath set, square metal plate, with thermostatic mixing, 3-way diverter, to be completed with built-in part

Recessed body required separately: CRICS800. Select the body matching the required installation layout.

Connections and fitting

Flush the pipework thoroughly before connecting the product. Follow the connection sizes, mounting ranges, pressure and temperature limits in the original manufacturer guidance. Use the supplied fixings and keep service connections accessible.

Commissioning and handover

Open the supplies gradually, inspect all connections for leaks and check operation of each outlet, control and diverter. Resolve any leak before handover. Give the owner the manufacturer instructions and care guide.

Fitting reference

Neither Cristina nor B&M links a dedicated fitting leaflet for CRIIT753. Use the exact dimensional drawing and supplied parts. Confirm connection sizes, recessed-body compatibility and final positions before installation. Ask B&M or Cristina for model-specific guidance where required.