CRISTINA

Care and Maintenance

CRIFT32051 | Fractal Series | Chrome

Routine cleaning

Clean finished surfaces regularly with a neutral soap-based detergent and a soft cloth, such as microfibre. Rinse thoroughly to remove cleaning residue and dry gently. Use the same gentle method on handles and trim.

Protect the surfaces

Do not use acidic or caustic cleaners, their derivatives, abrasive powders, scouring pads, or metal or non-metal abrasive sponges. Avoid abrasive polishes. Keep construction chemicals and aggressive cleaning residues away from the fitting.

Outlets and servicing

If flow becomes reduced or uneven, ask a competent plumber to inspect the appropriate outlet, aerator or filter using the method in the manufacturer instructions. Isolate the water before servicing. Use the correct service key and protect finished surfaces from tools.

Replacement parts

Quote CRIFT32051, purchase details and photographs when requesting assistance from B&M. Match the exact model and production revision. The original spare-parts notes distinguish historical components and finish-dependent references.

Selected finish

This SKU is finish 51 Chrome. Screen and printed colours may differ from the actual surface.

Reference: Cristina manufacturer maintenance and cleaning guidance in the fitting leaflets supplied with this SKU.