

CARE AND MAINTENANCE

Concealed Thermostatic Shower Mixer with Box - Anti-Stagnation

Bridgepoint SKU: IDM90H4-01000 Idral code: M90H4-01000

Surface cleaning

- Clean chrome-plated and stainless-steel surfaces with water and soap. Avoid aggressive liquids and dry with a soft/damp cloth.

Supply filters and valves

- If flow decreases, close the water supply and clean the supply filters. Confirm the non-return valves are clean and fully operational before reopening the supply.

Thermostatic cartridge

- If mixing problems persist after filter cleaning, remove the thermostatic cartridge and wash its filters under running water.
- For scale deposits, soak the cartridge in a suitable descaling solution or water and vinegar for 8-12 hours, then retest.
- Lubricate cartridge O-rings only with silicone grease. Do not use petroleum jelly or mineral grease. Replace the cartridge if correct operation cannot be restored.
- After servicing, verify the maximum mixed-water temperature and correct operation before returning the product to use.

Follow local plumbing regulations and use qualified personnel for installation and servicing.

Manufacturer source: Idral instruction ISTA27-01 for sequential/progressive thermostatic mixers.